


Parts of a VaporFlame System:

1. Air Compressor supplies air to VaporFlame Units
2. Water Pump supplies water to VaporFlame Units
3. Water/Air Hose connects water/air supply to Vaporflame units via Valved Quick Disconnect
4. VFc Body contains electronics, power and data connections
5. VFc Nozzle Hose carries water to Nozzle Head
6. Nozzle Head attaches to LED Fixture and creates vapor plume
7. LED Light Illuminates Vapor Plume to create flame effect.



1 **Mobile System**
Scale: 1:10

2 **Architectural Installation**
Scale: 1:10

Project Name		
VaporFlame System		
Vapor Flame	Drawn By	Date
L.Kaplan	8.12.22	
Notes		
Sheet 1	System Components	
<small>All Drawings and Information © VaporFlame™ Inc. - Do not share without express permission.</small>		